




Dell Inspiron 7568 Battery Replacement Guide

If you have issues with your Dell Inspiron 7568 battery and do not wish to keep buying chargers, here is a guide that shows you how to change it yourself!

Written By: Luis Velez



INTRODUCTION



By following the steps in this guide one should be able to replace the battery on the device (Dell Inspiron 7568).



TOOLS:



- Philips Head Screwdriver: Size PH1 (1)
-

Step 1 — Battery



- Unscrew & remove the ten 7mm screws (using a ph1 screwdriver) holding the bottom cover
- Remove the bottom cover

Step 2



- Unscrew & remove the four 3mm screws (using the ph1 screwdriver bit) holding the battery
- Unhinge the connector cable to the battery
- Remove the battery

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-10-08 07:01:21 PM.